

Put the tabletop on top of the assembly and fix with 4 x small washer and 4 x screw. Use an Allen key and apply normal force. DON'T USE A POWERTOOL.



6 You can use the adjustable feet to level the table.



Attention: Never move the table when it is assembled. In case the table has to be moved to a new location, always dismantle the top from the base to avoid damages.

ASSEMBLY INSTRUCTIONS

T-Table

D2162-x-x / D2163-x-x D2164-x-x / D2165-x-x D2166-x-x / D2167-x-x D2168-x-x / D2169-x-x D2170-x-x / D2171-x-x D2172-x-x / D2173-x-x D2174-x-x


D2160-x-x / D2161-x-x

TRIBÙ

Tribù nv Oude Heidestraat 72 3740 Bilzen BELGIUM

> www.tribu.com info@tribu.com

CONTENT




ASSEMBLY INSTRUCTIONS


T-Table is available in 3 table heights. Make sure you combine the correct threaded rod with the correct leg. The threaded rod is a little bit longer than the leg. These components are packed together.



Place the base in the designated location on a level surface and insert the threaded rod. Make sure the welded nut is facing downwards. Use the large washer. Make sure to tighten with a ring spanner.



Position the leg over the thread rod. Make sure it fits into the base. The 4 pins on the bottom side of the leg fit into 4 designated holes.



Position the top mount on the leg and fix with 1 x large washer and 1 x nut. Use a socket spanner to tighten with maximal force.

